

## **Swift Helicopter Start Up Procedures:**

1. Switch to desired channel on the transmitter, and then turn on transmitter.
2. Turn on helicopter; quickly place it on flat surface.
3. Point the transmitter at it, and move Throttle Stick to top and release it, this is the initialization of throttle range
4. They should bind up now.

## **Swift Helicopter Re-Charge Battery Procedures:**

### **Transmitter Charging :**

1. Please make sure you have good AA batteries in the Transmitter.
2. Connect the charging wire to the helicopter; make sure you connect it the correct way.
3. Then, turn on transmitter, you will see the Green Light, this means it is charging.
4. Wait until the Green Light goes out, this means charging complete. This usually takes around 20-30 minutes to fully charge a empty battery.

### **USB Cable Charging :**

1. Connect the USB wire to the computer.
2. Connect the other end to the helicopter; make sure you connect it the correct way.
3. The USB Cable's Red Light will go out, this means it is charging.
4. Wait until the Red Light appears again, this means charging complete. This usually takes around 20-30 minutes to fully charge a empty battery.